# Report: Network Traffic Sniffing

The program mydump.go provides implementation to carry live traffic or read from a tcp dump .pcap file with string pattern and BPF Filtering options.

# **Output and Program Usage**

Program Usage:

## \$sudo go run mydump.go

If we don't provide any parameters, it will take the default ethernet device and start sniffing live traffic

#### Sample Output:

#### \$sudo go run mydump.go -i en0

For the "i" parameter, it takes the ethernet device. If the ethernet device does not exist, the program stops giving an error "No such device exists (BIOCSETIF failed: Device not configured)".

#### Sample Output:

#### \$sudo go run mydump.go -r hw1.pcap

For the "r" parameter, it takes the file parameter. If the file parameter is wrong, it will exit.

# \$sudo go run mydump.go -i en0 -r hw1.pcap

If both the "i" and "r" parameters are given, the file will be taken into consideration and the program will start reading from the valid pcap file provided.

#### Sample Output:

Here you can see that the above output and this output is the same as both are reading from the same file. This command has overridden the interface input provided by the user.

#### \$sudo go run mydump.go -i en0 -r hw1.pcap -s "Gateway"

"S" parameter checks whether the packet payload has the provided string input or not. It will only dump the packet if the string is present in the packet payload.

#### Sample Output

#### \$sudo go run mydump.go -i en0 -r hw1.pcap "icmp"

Expression at the end of the command gives the BPF Filter which needs to be applied while dumping packets. If no such value is provided, no BPF Filter is applied.

#### Sample Output

There could be any combination of the parameters given. Only expression or string parameters are also applicable if i and r parameters are not provided. If neither i nor r parameters are provided, string or BPF expression filter will be applied on the dump provided by the default ethernet device.

# Code/ Implementation Walkthrough

- 1. Accept input parameter values , -i (for interface name), -r (for .pcap file), -s (for string) and flag.Args (for expression)
- 2. Depending on the input parameters, deciding whether to read from file, read online from device, or if unknown parameters, taking default device and start sniffing online
- 3. For default devices, **pcap.FindAllDevs()** returns all available interfaces. Took the first one in the list as the default.
- 4. Used **pcap.OpenOffline(filePointer)** to read from the pcap file
- 5. Used pcap.OpenLive(interfacePointer, 1600, true, pcap.BlockForever) to read from interface
- 6. After starting the handle to read from respective locations:
  - a. Setting the BPF Filter using:

# handle.SetBPFFilter(expressionPointer)

b. Extracting each packet:

### gopacket.NewPacketSource(handle, handle.LinkType())

- c. Running a loop for each packet
- d. If the string pattern parameter is present, checking the string in the payload to move forward:

## strings.Contains(string(ip.Payload), stringValue)

e. Printing time:

```
time := packet.Metadata().Timestamp.Format("2006-01-02 15:04:05.000000")
```

f. Printing ethernet layer details -> SrcMac, DstMac, hex value of Ethernet Type:

```
ethernetPacket, := ethernetPacketLayer.(*layers.Ethernet)
```

g. Printing packet length:

```
packet.Metadata().Length
```

h. Printing IP layer details if present-> Srclp, Dstlp:

```
ipLayer := packet.Layer(layers.LayerTypelPv4)
```

i. Printing TCP/UDP layer port details if it is a TCP/UDP packet

tcpLayer := packet.Layer(layers.LayerTypeTCP)
udpLayer := packet.Layer(layers.LayerTypeUDP)

j. Printing IP protocol:

ip.Protocol

- k. Printing TCP flags which are set to true if it is a TCP packet: **tcp.SYN, tcp.ACK**, etc.
- I. Printing ethernet layer payload as hex dump.

hex.Dump(ethernetPacket.Payload)

# References

- 1. <a href="https://pkg.go.dev/github.com/alicebob/pcap">https://pkg.go.dev/github.com/alicebob/pcap</a>
- 2. <a href="https://www.devdungeon.com/content/packet-capture-injection-and-analysis-gopacket">https://www.devdungeon.com/content/packet-capture-injection-and-analysis-gopacket</a>
- 3. <a href="https://pkg.go.dev/github.com/google/gopacket@v1.1.19/pcap">https://pkg.go.dev/github.com/google/gopacket@v1.1.19/pcap</a>
- 4. <a href="https://danielmiessler.com/study/tcpdump/">https://danielmiessler.com/study/tcpdump/</a>
- 5. https://pkg.go.dev/github.com/google/gopacket@v1.1.19